



FLOORING, INC.

130 Executive Drive
Calhoun, Georgia 30701-3067
E-Mail: sales@daltonian.com

706-602-7478
WATS 1-800-788-1408
FAX 706-602-7823

ADHESIVE REFERENCE

ABSORBER

Step One – New Drywall/Painted Surface:

Primer Needed. Gardner-Gibson Dynamite #221 acrylic wallcovering primer or Roman 909. Allow to dry overnight. Use 3/8" nap roller.

**Step Two – Application to Walls:
*Not to Wallpaper**

Adhesive: Gardner-Gibson Dynamite#234 heavy duty strippable adhesive or Roman Pro 870. Do not dilute. Allow to tak prior to installation.

Coverage:

Primer:

Gardner-Gibson Dynamite #221 or Roman 909/400-500 square feet per gallon.

Adhesive:

Gardner-Gibson Dynamite #234 or Roman 870. Approx. 150 square feet per Gallon, per coat. Use 3/8" Nap point roller.

Material Width:

4.5 feet or 54" (13.5 sq. ft./lin. yd.)

This application provides a strippable system for removal and repair purposes. Adhesives can be obtained from local paint stores such as: Sherwin-Williams, Pittsburgh Paints, Porter Paint, ICI paints, etc.