



130 Executive Drive
Calhoun, GA 30701-3067
E-Mail: sales@daltonian.com

706-602-7478
WATS 1-800-788-1408
FAX 706-602-7823

INSTALLATION GUIDELINES

DALTONIAN CUSHION TACKLESS APPLICATION

FLOOR PREPARATION

- Floors must be clean and free from all foreign matter (dust, grease, paint, varnish, chemicals, oil(s), wax detergents, etc.)

On TACKLESS Applications:

Maximum thickness of Cushion is 7/16”.

Minimum density of Cushion is 10-lb.

CUSHION:

- Installed in the longest lengths possible. (*Consider traffic pattern and seam placement*).
- Seams:
Should be at right angles to carpet or offset 6”- & tightly butted leaving no gaps...(*not directly beneath carpet seams*)
- Cushion must be securely fastened to substrate with staples (wood floors).
- Staples to be spaced 12” apart
- Substrates other than wood can be adhered with special purpose adhesive.
- Perimeter gluing of cushion is Not Permitted; however, spot gluing is allowed.
- Use Duct tape, vinyl covered fabric tape, etc. where seams occur.